

# **PERRIN**

## **PERFORMANCE**

### **02-07 WRX RADIATOR SHROUD**

122811

Thank you for purchasing the PERRIN Radiator shroud. Installation of this part can be performed by anyone with a 10 and 12mm socket or wrench, yes its that simple!

#### ***Parts Included with the PERRIN Radiator Shroud:***

- (1) PERRIN Aluminum Radiator Shroud

#### **INSTALLATION**

- 1) Locate and remove (2) 10mm bolts securing OEM intake scoop to car.
- 2) Locate and remove upper radiator brackets (2) 12mm bolts. One on each side of radiator.
- 3) Set PERRIN Radiator shroud onto car.
- 4) Reinstall OEM radiator support brackets, and tighten to 12ft-lbs. Some minor adjustment may be necessary to clear hood release bracket.
- 5) Reinstall OEM intake hood scoop and tighten bolts to 12ft-lbs.
- 6) Locate and remove short rubber trim mounted to hood directly over OEM intake scoop. If this piece is left in place, it can cause wear marks on the shroud.
- 7) Take car for test drive. You will know your radiator shroud is installed properly if your friends are envious of your engine bay when hood is lifted.

***For questions & comments please contact***

***[TECH@PERRINPERFORMANCE.COM](mailto:TECH@PERRINPERFORMANCE.COM)***

***503-693-1702***

***See Website for Live Chat Options***