

PERRIN

PERFORMANCE

SI Drive Cover

2014-02-11

Thank you for purchasing this PERRIN product for your car! Installation of this product should only be performed by persons experienced with installation of aftermarket performance parts and proper operation of high performance vehicles. If vehicle needs to be raised off the ground for installation, the installer must use proper jacks, jack-stands and/or a professional vehicle hoist for safety of the installer and to protect property. If the vehicle is lifted improperly, serious injury or death may occur! Please read through all instructions before performing any portion of installation. If you have any questions, please contact our tech department prior to starting installation. We can be reached in any of the following methods:

Email Tech@PERRINperformance.com
Instant Chat off the main page of www.PERRINperformance.com
Or simply call our tech team at 503-693-1702

Parts Included with the PERRIN SI Drive Cover:

- (1) PERRIN SI Drive Cover
- (1) Silver PERRIN Logo
- (1) Black PERRIN logo

Installation of PERRIN SI Drive Cover

1. Locate SI Drive Knob on your STI. Make sure surface is clean and free of oils/dashboard shining products. **NOTE: Use a small amount of rubbing alcohol on the surface to clean.**
2. Under PERRIN SI Drive Cover, locate adhesive tape and remove backing from strip.
3. Using small circle on top of PERRIN SI Drive Cover as a guide, place cover over factory SI drive knob. **Note: Make sure to place cover over knob slowly and as straight as possible. This will provide best results. If SI Drive Cover is installed crooked, pull off or twist off quickly and redo this step.**
4. Once PERRIN SI Drive Cover is installed to your liking, press down on cover for roughly 20 seconds. **NOTE: Double-sided tape will be 75% bonded to cover after 2 hours. It will be fully bonded after 72 hours. If for any reason you have to remove cover, please contact us and we will provide additional adhesive for you to re attach.**
5. Now decide if you want to leave the cover the way it is or install one of (2) included labels. If you choose to install a label, peel off backing and place on top of cover.

Questions, Comments and Suggestions Contact:

Tech@PERRINperformance.com

Visit Our Website for Instant Chat Options at www.PERRINperformance.com

Call Our Tech Team at 503-693-1702